## Use and maintenance instructions EDGE WALL, EDGE WALL 90°, EDGE WALL 60°

Fixed general purpose luminaire, for wall mounting. TECHNICAL DETAILS: please refer to the product label



WARNINGS: The UE declaration of conformity can be downloaded from our website www.marecoluce.it • THE SAFETY OF THIS PRODUCT IS GUARANTEED ONLY WITH THE RESPECT OF THE EXISTING RULES FOR THE ELECTRICAL SYSTEMS, AND WITH THE APPROPRIATE USE OF THESE INSTALLATION INSTRUCTIONS, THEREFORE IT IS NECESSARY TO KEEP THEM. • THE IMPROPER USE OF THIS PRODUCT IS FORBIDDEN; ANY TAMPERING WITH THE PRODUCT OR MODIFICATION OF THE PRODUCT THAT IS NOT AUTHORIZED BY MARECO LUCE CAN CAUSE Insulation Class II DAMAGE TO PEOPLE, ANIMALS OR THINGS, AND WILL VOID ANY WARRANTY OR LIABILITY. • SWITCH OFF THE ELECTRICITY BEFORE CONDUCTING ANY KIND OF MAINTENANCE. • THE PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH BEST PRACTICE. • THE LIGHTING SOURCE OF THIS LUMINAIRE MUST BE REPLACED BY THE MANUFACTURER ONLY. **IP65** Protection degree against dust ingress, solid particles, moisture • DAMAGED COMPONENTS MUST BE REPLACED WITH MARECOLUCE ORIGINAL SPARE PARTS. • THE MANUFACTURER IS NOT AT ALL RESPONSIBLE FOR THE CHOICE OF THE MOUNTING SURFACE OF THE BRACKET AND THE CHOICE OF THE FIXING TOOLS. • THE MANUFACTURER IS NOT AT ALL RESPONSIBLE FOR THE HEIGHT AT WHICH THE LUMINAIRE IS INSTALLED. X This product must not be disposed as a normal household waste **GENERAL MAINTENANCE RECOMMENDATIONS:** • CLEAN THE LUMINAIRE PERIODICALLY TO REMOVE THE POSSIBLE DIRT DEPOSITS ON IT. • DO NOT USE HARSH DETERGENTS TO CLEAN THE DIFFUSER. • CHECK THAT THE FIXING SCREWS OF THE BRACKET TO THE MOUNTING SURFACE. (NOT INCLUDED) AND THE FIXING SCREWS OF THE BRACKET TO THE LUMINAIRE (INCLUDED) Caution, risk of electrical shock. The lighting source of this luminaire must be

ARE FULLY TIGHTENED.

• CHECK THE INTEGRITY OF THE FITTING COMPONENTS: REPLACE THEM IN CASE OF DAMAGE BY USING ONLY ORIGINAL MARECO LUCE PARTS.

## **INSTALLATION INSTRUCTIONS:**

replaced by the Manufacturer only


14

1. Lift the protective cover (3), unscrew the screws (4) and remove the bracket (1). 2. Fasten the bracket (1) to the slots or holes using some screws and expansion plugs, (NOT INCLUDED).

CAUTION: Choose screws and expansion caps suitable for the type of installation that you are conducting.


3. Connect the luminaire to the mains throughout a watertight connection, and paying attention to respect both the polarities and the insulation class. 4. Insert the luminaire (2) into the bracket (1), lift the protective cover (3) and secure the luminaire to the bracket (1) by tightening the 4 screws (4) applying 5Nm. 5. Refit the protective cover (3).

Edge wall 90° Edge wall Edge wall 90°/60° T m д д Д Д ΰ ΰ Edge wall 60° ΠД 2 4 l l 2 **4** 0 Flange for wall fixing: Fixing holes Ø6.2mm Holes Ø14 60 88 Wall fixing bracket: fixing holes Ø5.2mm



Edge wall 

250mm - min



Edge

wall

Edge wall 60°

Edge

wall 90°

Rev. 3-08/03/2021