

47032 Bertinoro (FC) Italia


Use and maintenance instructions New Stelo

Outdoor luminaire suitable for installation on concrete plinth.

TECHNICAL DETAILS: refer to the product label



The UE declaration of conformity can be downloaded from our website www.marecoluce.it



IP65 Protection degree against dust ingress, solid particles, moisture



This product must not be disposed as a normal household waste

WARNINGS:

• THE SAFETY OF THIS PRODUCT IS GUARANTEED ONLY WITH THE RESPECT OF THE EXISTING RULES FOR THE ELECTRICAL SYSTEMS, AND WITH THE APPROPRIATE USE OF THESE INSTALLATION INSTRUCTIONS, THEREFORE IT IS NECESSARY TO KEEP THEM.

• THE IMPROPER USE OF THIS PRODUCT IS FORBIDDEN; ANY TAMPERING WITH THE PRODUCT OR MODIFICATION OF THE PRODUCT THAT IS NOT AUTHORIZED BY MARECO LUCE CAN CAUSE DAMAGE TO PEOPLE, ANIMALS OR THINGS, AND WILL VOID ANY WARRANTY OR LIABILITY.

• SWITCH OFF THE ELECTRICITY BEFORE CONDUCTING ANY KIND OF MAINTENANCE.

- THIS PRODUCT IS SUITABLE FOR OUTDOOR INSTALLATION ONLY.
- THE PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH BEST PRACTICE.
- DAMAGED COMPONENTS MUST BE REPLACED WITH MARECOLUCE ORIGINAL SPARE PARTS.
- DO NOT PLACE ANY OBJECT ON THE DIFFUSER AND DO NOT COVER IT.

• MAX. LAMP SIZE (IN MM):

11W D60 L115



GENERAL MAINTENANCE RECOMMENDATIONS:

• THE BASE AND THE OTHER PARTS OF THE PRODUCT CANNOT BE COVERED BY SOIL OR PUT IN CONTACT WITH AGGRESSIVE CHEMICAL SUBSTANCES (HERBICIDES, FERTILIZINGS, ETC).

- CLEAN THE FITTING PERIODICALLY TO REMOVE POSSIBLE DIRT/GROUND DEPOSITS
- DO NOT USE HARSH DETERGENTS TO CLEAN THE DIFFUSER
- CHECK THE TIGHTNESS OF THE SCREW SECURING THE FITTING.
- CHECK THE INTEGRITY OF THE FITTING COMPONENTS: REPLACE THEM IN CASE OF DAMAGE BY USING ONLY
 ORIGINAL MARECO LUCE PARTS
- CHECK THE PLASTIC CASINGS CAREFULLY IN ORDER TO IDENTIFY ANY POSSIBLE INSULATION DAMAGE.

INSTALLATION INSTRUCTIONS:

1. Connect the cable out of the fitting (1) to the main supply by respecting the polarities

CAUTION: For a correct installation, we recommend to ensure a watertight connection between the supply cables and to use only a flexible double insulation sheath (type HAR) or one suitable for outdoor use.

2. Install the bollard from the base (3) and place it over the plinth by using the screws and expansion caps (NOT included in the packaging).

- 3. Remove the diffuser (4) to access to the lamp holder (2).
- 4. Insert the lamp (NOT included with the luminaire).
- 5. Tighten the diffuser (4) and make sure that the gasket is in the correct position

