

### **ASSEMBLY INSTRUCTIONS**




LUX EST applique 90°

# 🖄 IP44 🕱 ( E 🖲 🛆 🗆

# wall IP40 $\mathbf{\zeta} \in \mathbf{\nabla} \square$ ceiling $\mathbf{\zeta} \in \mathbf{\nabla} \square$ IP43

#### WARNINGS:

- \* THE INSTALLATION AND THE MAINTENANCE OF THE PRODUCT MUST BE DONE BY PROFESSIONAL INSTALLERS.
- \* THE SAFETY OF THIS PRODUCT IS GUARANTEED ONLY WITH THE APPROPRIATE USE OF THESE INSTALLATION INSTRUCTIONS WHICH MUST BE RETAINED.
- \* TOGLIERE LA TENSIONE PRIMA DI EFFETTUARE QUALSIASI TIPO DI MANUTENZIONE.
- \* SWITCH OFF THE ELECTRICITY BEFORE CONDUCTING ANY KIND OF MAINTENANCE.
- \* ONLY <u>OUTDOOR</u> INSTALLATION IS ALLOWED.
- \* THE BASE AND THE OTHER PARTS OF THE PRODUCT CAN NOT BE COVERED BY SOIL OR PUT IN CONTACT WITH AGGRESSIVE CHEMICAL SUBSTANCES (HERBICIDES, FERTILIZINGS, ETC..).
- \* DO NOT REST OBJECTS ON THE DIFFUSER, DO NOT COVER OR OBSCURE IN ANY WAY
- \* CLEAN PERIODICALLY THE PARTS COVERED BY SOIL.
- \* IT IS ADVISABLE TO USE THE SILICONE GREASE ON THE THREADED PARTS OF THE CLOSING SCREWS, IN ORDER TO MAKE THE FURTHER MAINTENANCE EASIER.
- \* The versions pre-set for LAMP 27W can be equipped with LAMPS of Max. dimension Ø65  $L\,200\,\text{mm}$  .
- \* The versions pre-set for LAMP 21W can be equipped with LAMP of Max. Dimension  $\varnothing65\,L\,155$  mm.
- \* The versions pre-set for LAMP 12W can be equipped with LAMP of Max. Dimension  $\varnothing65\,L\,111$  Mm.




## NS INSTRUCTIONS FOR THE INSTALLATION – FBT version:

1. Untighten the screws (1) and remove the square cover (aluminium body+diffuser) (2).

- 2. Untighten the screws (3) and remove the lamp holder.
- 3. Insert the supply cable through the cable tray.
- 4. Fix the base **(4)** to the mounting surface through some screws and expansions caps (not included).
- 5. Connect the supply cables to the lamp holder and tighten the screws (3).
- 6. Insert the lamp (not included).
- 7. Insert the square cover (2) into the base (4) and tighten the screws (1).

# **INSTRUCTIONS FOR THE INSTALLATION – FSQ version:**

- 1. Untighten the screws (1) and remove the square cover (aluminium body+diffuser) (2).
- 2. Remove the lamp holder (3).



- 3. Untighten the screws (4) and remove the bracket (5).
- 4. Insert the supply cable through the cable tray.
- 5. Fix the base **(6)** to the mounting surface through some screws and expansions caps (not included).
- 6. Connect the supply cable to the terminal **(7)**.
- 7. Position the bracket **(5)** and tighten the screws **(4)**.
- Insert the lamp holder on the bracket and put the lamp (not included)
- Insert the square cover (2) into the base (6) and tighten the screws (1).