

This document is exclusive MARECO LUCE s.r.l., is strictly prohibited disclosure or reproduction, even partial, as well the use of without written consent of MARECO LUCE s.r.l..The company reserves the right to change models, dimensions and materials at any time without notice.

PRODUCT DATA SHEET

Grid connection Stud solar

Code : CS160001

Connection of main supply cable (if available)

- The main supply cable coming out of the pole must be connected as follows:

- Clamp mark F Live wire
- Clamp mark N Neutral wire
- Clamp mark T Ground wire

- Movement sensor: Stud Solar 1/2 is pre-set for the connection of the remote sensor through a terminal block placed inside the electrical compartment. The sensor must be in "clean contact" with a supply voltage between 12VDC and 17VDC

Details

- IP

